

3680 INDOOR SHOT PUT TOEBOARD ASSEMBLY INSTRUCTIONS

The 3680 Wood Shot Indoor Toeboard is designed to be used with the 368 Indoor Shot/Weight Throw Circle. Wood screws are provided to attach toeboard to 368 circle as shown below. The toeboard is fabricated from select yellow pine and sealed with two coats of white enamel paint. The 3680 toeboard, in combination with the 368 Throwing Circle, meets all NCAA requirements.

Tools needed:
- Electric drill/driver

Parts list:
(1) Wood toeboard (3680)
(1) Indoor throwing circle (sold separately)
(4) 2" wood screws

